

Test Results Report

for

TeraRanger Evo 3m sensor

Date: September 2018

Authors: Gaultier Gaillard Clement Peltraut

Terabee is an official CERN Technology Partner:



Proprietary & Confidential

Phone: +33 (0)6 81 28 70 24

Email: teraranger@terabee.com

Web: www.terabee.com www.teraranger.com

Address: Terabee, 90 Rue Henri Fabre 01630, Saint-Genis-Pouilly France



Document Control

Change Record					
Date	Author	Versio	on Change reference		
03.09.2018	GGA	1.0	First draft		
05.03.2018	CW	1.1	Minor changes to make readable	it more	
Conter	nts				
Document C	Control				
Confidentiality					
<u>Change</u>	Record				
Contents					
Introduction					
Setup description					
<u>Test ber</u>	<u>ich description</u>				
<u>Test exp</u>	erimental protocol				
<u>Target d</u>	<u>escription</u>				
Sensor perfe	ormance evaluation				
Testing	condition				
Results					
Conclus	ion				
<u>Use Case te</u>	est example				
Test N°1					
Test	ing condition				
Resi	<u>ults</u>				
Test N°2					
Test	ing condition				
Resu	<u>ilts</u>				
Cond	<u>clusion</u>				
Test	ing condition				
Conclusion					



1. Introduction

The aim of this document is to show the behavior of the sensor in controlled indoor conditions and to give greater insight into the sensor specification sheet, notably around the maximum range and the accuracy of the sensor readings.

For these tests, up to 45 TeraRanger Evo 3m sensors were used with TeraRanger USB backboards. To help validate the tests, crosscheck tests were also run using the TeraRanger UART/I2C backboard, and on multiple sensors.

2. Setup description

2.1. Test bench description

For each of the following tests described in section 3, the following setup was used:

- The sensor was mounted on a trolley driven along a rail perpendicular to the target. The sensor was linked to a computer to collect the data. The data was streamed via Hterm terminal software.
- The target was fixed. Only the sensor was moved in relation to the target to change the measured distance.
- The sensor was positioned at a height that guarantees the FoV of the sensor does not point at the floor at a distance of 3m from the target (which is the maximum range of the TeraRanger Evo 3m.)
- A calibrated laser measurement device was attached to the platform and considered as a benchmark.



Fig.1.Top View schematic of the test bench



2.2. Test objective

The aim of the test is to report sensor accuracy based on varying targets and *Near InfraRed (NIR)* light conditions. Three different target surfaces have been tested and three different NIR light levels, in indoor conditions.

2.3. Target description

The different targets are described below.

Target #1 : White wall, light level 1*	Target #2 : White wall, light level 2*	
Target #3 : White wall, light level 3*	Target #4 : Cardboard, light level 1*	
	*Light level : the light level is defined by a scale of 3 different Infrared illumination levels. Level 1 : is typical of an indoor office condition (under neon light) without NIR on the target. Level 2 : is representative of an indoor office condition (neon light) with a low emission of NIR light to the target, equivalent to a reading lamp. Level 3 : is an indoor office condition (neon light) with a medium emission of NIR light to the target equivalent of a balagen lamp in a	
Target #5 : Wood box, light level 1*	room.	



3. Sensor performance evaluation

3.1. Testing condition

We evaluated the TeraRanger Evo 3m sensor in the specific environment, as described below:

Target: #1 Temperature: 20°C Humidity: 50% Number of sensors tested: 45pcs Distances tested: 40/100/175/240/290 cm



3.2. Results

Graph 1.TR-Evo 3m distance error on white target Light level 1



	Number of measurements	Percentage (%)
Error within +/- 2cm	210	93.33
Error outside +/- 2cm	15	6.67
Total	225	100.00

3.3. Conclusion

Based on these results, Terabee can confidently claim that the performance of the TeraRanger Evo 3m is within the +/- 2cm accuracy declared on the spec sheet in controlled, indoor conditions.



4. Use case test example

4.1. Test N°1

4.1.1. Testing condition

Target : #2 Temperature : 20°C Humidity : 70% Number of sensors tested : 7pcs Distances tested : 40/100/175/240/290 cm



4.1.2. Results

Graph 2.TR-Evo 3m distance error on white target Light level 2

4.1.3. Conclusion

Based on these results, we can see that the accuracy of the TeraRanger Evo 3m is slightly affected in the close range, below 50cm, but remains stable and within the +/- 2cm accuracy up to the 2m range. At this NIR light level, and above 2m range, accuracy is reduced, generally tending to slip outside of the +/-2cm accuracy.



4.2. Test N°2

4.2.1. Testing condition

Target : #3 Temperature : 20°C Humidity : 70% Number of sensors tested : 7pcs Distances tested : 40/100/175/240/290 cm



4.2.2. Results

Graph3.TR-Evo 3m distance error on white target Light level 3

4.2.3. Conclusion

Based on these results we can see that with increased NIR light (level 3) the performance of the TeraRanger Evo 3m is affected more adversely, especially at ranges in excess of 2m.



4.3. Test N°3

4.3.1. Testing condition

Target : #4 & #5 Temperature : 20°C Humidity : 70% Number of sensors tested : 1pcs Distances tested : from 10cm to 300cm at 10cm measurement intervals





Graph 4.TR-Evo 3m Sensor 1 distance error Light level 1

4.3.3. Conclusion

Graph 4 illustrates that the +/-2cm accuracy is achieved not only within controlled test environments (white wall) but also measuring against two random, non-controlled target surfaces (wood and cardboard).



5. Conclusion

Performance of the TeraRanger Evo 3m has been evaluated in indoor conditions, with a control target and with wood and cardboard targets. The +/-2cm accuracy is reliably achieved in these conditions.

In conclusion, we can state that the highest performance is reached in indoor conditions where lower interference from NIR is encountered. NIR interference will rise when direct sunlight is introduced to the target surface. - The brighter the sun, the greater the ambient NIR, but remember that NIR interference can also be introduced by halogen lamps and other external sources. The graph below shows a representation of the potential non-linear effect of increasing NIR.



Graph 5.TR-Evo 3m Error compared to NIR spectral irradiance